

hama®

MOBILE ENTERTAINMENT

MP3-Speaker »AS195«

MP3 Çalar Hoparlörü

hama®

Hama GmbH & Co KG
D-86651 Monheim/Germany
www.hama.com



T1027195/04.08

All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.

T1027195

MP3-Speaker »AS195«

Description



Getting started

- Insert the supplied batteries (type AAA) into the speaker system. You have the option of using a suitable power supply (not included; output 2 – 5 V, 500 – 1000 mA).
- Place the speaker system on a flat surface.
- Connect an external audio source (mobile phone, MP3 player, etc.) to the rear connection of the loudspeaker system for playback. You may have to use an appropriate adapter depending on the device type. (Hama Mobile Music Adaptor not included.) The loudspeaker system is now ready for use.
- Switch on the external signal source.
- Switch on the loudspeaker system with the rear ON/OFF switch. The blue LED indicates the device is ready for use.
- If the LEDs become weaker after considerable time, this indicates that the batteries should be replaced.

Please note:


In order to avoid possible feedback when switching the loudspeaker system on, we recommend switching on the connected audio source first.

Specifications

Frequency range:	200 – 20,000 Hz
Power RMS:	2 x 2 W
Connection:	3.5 mm jack plug
Power supply:	4 x AAA micro batteries (included)
Dimensions:	125 x 80 x 25 mm (folded)

»AS195« MP3 Çalar Hoparlörü

Başlangıç



- »AS195« 4 adet AAA pili cihazın pil yuvasına yerleştirin. Ayrıca cihaza uygun başka bir güç kaynağı da kullanabilirsiniz. (kutuya dahil değildir; çıkış 2-5V, 500-1000 mA)
- Hoparlörü düz bir zemine yerleştirin.
- Harici ses kaynağını (cep telefonu, MP3 çalar vs.) hoparlör sisteminin arkasındaki girişe bağlayın. (kullanılan cihazın modeline göre uygun bir adaptör kullanmanız gerekebilir) Hoparlör sisteminiz artık kullanıma hazırdır.
- Harici sinyal kaynağını çalıştırın.
- Hoparlör sisteminin cihazın arka kısmındaki ON/OFF düğmesini kullanarak çalıştırın. Mavi ışık cihazın çalıştığını gösterir.
- Belli bir kullanımdan sonra mavi ışık zayıfladığında cihazın pillerini değiştirmeniz gerekmektedir.

Dikkat:

İlk başta hoparlöre bağlı olduğunuz ses kaynağını çalıştırınız. Ardından hoparlörü, cihazın arkasındaki ON/OFF düğmesini kullanarak çalıştırınız.

Özellikler:

Frekans aralığı:	200 – 20,000 Hz
Güç RMS:	2 x 2 W
Bağlantı:	3.5 mm jack plug
Güç kaynağı:	4 x AAA micro pil (kutuya dahil değildir)
Ölçüler:	125 x 80 x 25 mm (cihaz katlandığında)